# MSD<sup>®</sup> 384-Well MULTI-ARRAY<sup>®</sup> Phospho-STAT4 (Tyr693) Assay

The following assay protocol has been optimized for quantifying phosphorylated STAT4 at tyrosine 693 in whole cell lysate.

		<u>Storage</u>
Materials Included		
	Read Buffer T (with surfactant), 4X	RT
	Blocker A	RT
	MULTI-ARRAY <sup>®</sup> 384-well Phospho-STAT4 (Tyr693) Plate(s)	2-8°C
	SULFO-TAG™ Anti-Total STAT4 (50X)	2-8°C
	Tris Wash Buffer (10X)	2-8°C
	Tris Lysis Buffer (1X)	2-8°C
	Phosphatase Inhibitor I (100X)	2-8°C
	Phosphatase Inhibitor II (100X)	2-8°C
	Blocker D-M (2%)	≤-10°C <sup>1</sup>
	Blocker D-R (10%)	≤-10ºC <sup>1</sup>
	Protease Inhibitor Solution (50X)	≤-10ºC

# Other Materials & Equipment (not supplied)

- Deionized water for diluting Wash Buffer and Read Buffer
- One 1 L bottle
- □ Two 50 mL tubes
- □ One 15 mL tube
- Adhesive plate seals
- Microtiter plate shaker
- □ Various microcentrifuge tubes for making serial dilutions of lysates (if desired)
- Automated plate washer or other efficient multi-channel pipetting equipment for washing 384-well plates
- Appropriate liquid handling equipment for desired throughput that must accurately dispense 10, 20, and 35 μL into a 384-well micro plate

FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC OR THERAPEUTIC PROCEDURES.



<sup>&</sup>lt;sup>1</sup> Blockers D-M and D-R can tolerate up to 5 freeze-thaw cycles. Alternatively, an aliquot of blockers D-M and D-R can be stored at 2-8°C for up to 1 month.

# Protocol at a Glance

The following protocol describes the most conservative approach toward achieving highly sensitive results using MSD technology to quantify phosphoproteins. The protocol can be completed in approximately 5 to 5 1/2 hours if each reagent is prepared during the preceding incubation. All reagents with the exception of diluted lysates can also be prepared ahead of time. This lengthens the overall time required for the assay but frees up time during incubation steps.

Once desired results are achieved, the protocol can be streamlined to eliminate multiple incubation and wash steps to increase throughput.

- 1. Add Blocking Solution, incubate 1 hour, wash.
- 2. Add lysate, incubate 2 hours at room temperature, wash.
- 3. Add Detection Antibody, incubate 2 hours, wash.
- 4. Add Read Buffer and analyze plate.

## Detailed Instructions

#### Prepare a stock of 1X Tris Wash Buffer:

- a) The stock of 1X Tris Wash Buffer will be used throughout the assay to make other reagents as well as wash plates. Approximately 1 L per plate is required- more if using an automatic plate washer.
- b) In a 1 L bottle combine:
  - □ 100 mL 10X Tris Wash Buffer
  - □ 900 mL deionized water

#### **Prepare Blocking Solution-A:**

- a) Prepare 20 mL per plate.
- b) In a 50 ml tube combine:
  - □ 20 mL 1X Tris Wash Buffer
  - □ Blocker A 600mg (3%)

#### **Prepare Antibody Dilution Buffer:**

- a) Prepare 8 mL per plate.
- b) In a 15 mL tube combine:
  - □ 2.67 mL Blocking Solution-A
  - □ 4.85 mL 1X Tris Wash Buffer
  - □ 400 µL 2% Blocker D-M
  - $\square$  80 µL 10% Blocker D-R



Read the entire detailed instructions before beginning work.

Notes:

A larger amount of Tris Wash Buffer may be prepared at once and stored at room temperature for later use.

Solutions containing Blocker A should be kept at 4°C and discarded after 14 days.

#### Notes:

Begin with a MULTI-SPOT 384-well 1 Spot Phospho-STAT4 (Tyr693) Plate. No pre-treatment is necessary.

STEP 1 Add 35 µL/well of Blocking Solution.

Incubate with shaking at room temperature for 1 hour. Prepare Complete Tris Lysis Buffer, and dilute cell lysates during this time.

### Prepare Complete Tris Lysis Buffer:

- a) To 10 mL of Tris Lysis Buffer, add the following:
  - □ 100 µL Phosphatase Inhibitor I (100X stock)
  - **□** 100 μL Phosphatase Inhibitor II (100X stock)
  - **Δ** 200 μL Protease Inhibitor Solution (50X stock)
- b) Keep Complete Tris Lysis Buffer on ice until use.

#### Prepare samples or positive and negative cell lysates:

(Note: Recommendations for cell lysate handling are provided; however, the suggested concentrations listed below may need to be adjusted depending upon specific samples tested.)

- a) Thaw cell lysate samples on ice and dilute immediately before use. Keep on ice during all manipulations and discard all remaining thawed unused material.
- b) Dilute positive and negative cell lysates in Complete Tris Lysis Buffer to a final concentration of 0.5 μg/μL. This will deliver 5 μg/well in 10 μL. A dilution series may also be prepared if desired.

Wash plates three times with Wash Buffer.

STEP 2 Dispense 10 µL/well of diluted lysates.

Incubate with shaking for 2 hours at room temperature. Prepare SULFO-TAG Anti-Total STAT4 Detection Antibody solution during this time.

#### **Prepare Detection Antibody Solution:**

- a) Prepare 8.0 mL per plate.
- b) In a 15 mL tube combine:
  - a. 7.84 mL cold Antibody Dilution Buffer
  - b. 160 µL 50X Anti-Total STAT4 Antibody (Final concentration: 1X)

Wash plates three times with Wash Buffer.



Plates may also be blocked overnight at 4°C.

Complete Tris Lysis Buffer should be made each day of experimentation.

The Complete Tris Lysis Buffer should be ice cold before use.

Complete Tris Lysis Buffer should be made immediately prior to use.

Shaking a 384-well MSD MULTI-ARRAY or MULTI-SPOT<sup>®</sup> plate accelerates capture at the working electrode.

Notes:

### STEP 3 Add 10 µL/well of Detection Antibody Solution.

Incubate with shaking at room temperature for 2 hours. Prepare Read Buffer during this time.

#### **Dilute Read Buffer:**

In a 50 mL tube, combine (per plate):

 $\Box$  15 mL deionized water

Wash plates three times with Wash Buffer.

STEP 4 Add 35 µL/well of diluted Read Buffer T (with surfactant).

Analyze with SECTOR<sup>®</sup> Imager plate reader.

Diluted Read Buffer may be kept in a tightly sealed container at room temperature for later use.

Bubbles in the Read Buffer will interfere with reliable imaging of the plate if carried into the wells.

Plates can be imaged immediately following the addition of Read Buffer.

Meso Scale Discovery, Meso Scale Diagnostics, www.mesoscale.com, MSD, MSD (design), Discovery Workbench, Quickplex, Multi-Array, Multi-Spot, Sulfo-Tag and Sector are trademarks of Meso Scale Diagnostics, LLC. © 2009 Meso Scale Discovery a division of Meso Scale Diagnostics, LLC. All rights reserved.